



*hallicrafters*

OPERATING AND SERVICE INSTRUCTIONS

---

**FOUR-BAND  
COMMUNICATIONS RECEIVER  
MODEL SX-122**




Figure 1. Hallicrafters' Model SX-122 Receiver.

156-001957

## SECTION I

### GENERAL DESCRIPTION

The Hallicrafters' Model SX-122 Communications Receiver is a four-band dual-conversion super-heterodyne receiver tuning from 540 to 1600 kilocycles (KC) and 1.75 to 34 megacycles (MC) with calibrated electrical bandspread provided on the 80, 40, 20, 15, 10 meter and citizens bands. The frequency range covers foreign and domestic short-wave broadcasts, amateurs, aircraft, and marine plus standard AM broadcasts. The receiver provides for the reception of code (CW), voice (AM), and single-sideband (SSB) signals over its entire tuning range, the upper or lower sideband being readily selectable by means of a front-panel control. This feature greatly simplifies tuning of single-sideband signals.

The SX-122 Receiver employs dual conversion on all bands to obtain optimum image rejection. A high order of selectivity is made possible by the use of a 50-KC second-IF system with four high-Q, permeability-tuned circuits. Receiver selectivity is variable in three steps: 0.5 KC, 2.5 KC, and 5 KC at 6 DB down.

A tuned-RF stage assures maximum sensitivity and a high signal-to-noise ratio for outstanding reception of weak and distant signals. A manual RF gain control prevents overloading by strong signals. An antenna trimmer, adjustable from the front panel, permits peaking of the RF stage to compensate for loading effects of various antennas.

Outstanding frequency stability is achieved by the use of: 1) ceramic trimmers and coil forms in the first-conversion oscillator, 2) extensive temperature compensation, 3) voltage regulation of

oscillators, and 4) a crystal-controlled, second-conversion oscillator.

Tuning is accomplished by a precision tuning mechanism to insure close calibration and accurate resettability. Smooth flywheel tuning affords maximum traverse speed and operating ease.

Provisions have been incorporated to accept, as an accessory, a 100-KC Crystal Calibrator, Model HA-7. This crystal calibrator provides marker signals at every 100 KC on the dial for checking calibration accuracy.

An automatic series noise limiter circuit, controlled by a switch on the front panel, reduces interference from electrical equipment, ignition noise, and other forms of pulse-type noise.

An S meter is used to indicate the accuracy of tuning and the relative strength of received signals. The meter is calibrated in S units from 1 to 9, and in decibels above S9.

Provision has been made in the receiver for a remote receive-standby control.

Audio output connections include terminals for a 3.2-ohm speaker. A front-panel jack is also provided for using headphones and the speaker is automatically silenced when the headphone plug is inserted.

The receiver is designed to operate on 105 to 125 volt, 50/60 cycle, AC current.

## SECTION II INSTALLATION

### 2-1. UNPACKING.

After unpacking the receiver, examine it closely for damage which may have occurred in transit. Should any sign of damage be apparent, immediately file a claim with the carrier stating the extent of damage. Carefully check all shipping labels and tags for instructions before removing or destroying them.

### 2-2. LOCATION.

The receiver may be placed in any location that will permit free air circulation through the ventilation holes and openings in the cabinet. Avoid excessively warm locations such as those near radiators and heating vents. The external speaker may be located in any convenient position, although it is recommended that it not be placed on top of the receiver for reasons of ventilation.

### 2-3. ANTENNAS.

The RF input of the receiver is designed for operation from either a single-wire antenna, a half-wave doublet, or other antenna with a transmission-line impedance from 50 to 600 ohms. Antenna connections are made to a three-terminal strip at the rear of the receiver marked A1, A2, and GND. Mounting holes are also provided, adjacent to the antenna terminals, for installation of an AN type SO-239 connector for coaxial-cable installations.

#### A. SINGLE-WIRE ANTENNA

The simplest antenna that will provide satisfactory results throughout the entire tuning range is a conventional single-wire antenna. In most localities, good results can be obtained with just the 15-foot length of antenna wire supplied with the receiver. (See figure 2.) Attach one end of the wire to terminal A1, connect the jumper link between terminals A2 and GND, and then extend the wire about the room in a convenient manner. If the receiver is operated in a steel-constructed building or where receiving conditions are exceptionally poor, an outside antenna, 50 to 100 feet long, may be necessary. The outside antenna should be erected as high as possible and kept free from surrounding objects.

In some locations, reception may be improved by connecting a ground wire (ordinary copper wire) from terminal GND to a cold-water pipe or outside ground rod. While the use of an outside ground rod installed in accordance with Insurance Underwriter's Laboratories requirements is adequate




Figure 2. Single Wire Antenna Installation.

protection against lightning, it is strongly recommended that an additional connection be made to the nearest cold-water pipe to eliminate any shock hazard.

#### B. HALF-WAVE DOUBLET ANTENNA

For top performance, especially on the short-wave bands, the use of a half-wave doublet or other type of antenna employing a 50 to 600 ohm transmission line is recommended. A typical doublet antenna installation is shown in figure 3. The doublet antenna should be cut to the proper length for the most used frequency or band of frequencies. The formula for determining the overall length in feet of a doublet antenna is included in figure 3.




Figure 3. Typical Doublet Antenna Installation.

The doublet antenna is directional and should be erected with its entire length facing a desired station for maximum signal pickup.

The doublet antenna may be fed with either a balanced or unbalanced transmission line. When a balanced line such as *twin-lead* or *twisted pair* is used, the line connects to terminals A1 and A2 and the jumper link between A2 and GND is disconnected. (See figure 3.) When using an unbalanced line such as coaxial cable, the inner conductor connects to terminal A1, the outer braid connects to terminal A2, and the jumper link is connected between terminals A2 and GND. A ground wire may improve reception when using an unbalanced-type line.

The doublet antenna provides optimum performance only at or near the frequency for which it is cut. Therefore it may be desirable, for reception on frequencies remote from the antenna frequency, to utilize the doublet antenna as a single-wire type. This is accomplished by connecting the two transmission-line leads together and connecting them to terminal A1. The jumper link in this case should be connected between terminals A2 and GND.

In an installation where the receiver is used in conjunction with a transmitter, it may be advantageous to use the same antenna for receiving as for transmitting. This is especially true when a directional antenna is used, since the directive effects and power gain of the transmitting antenna are the same for receiving as for transmitting. Switching the antenna from the transmitter to the receiver may be accomplished with an antenna-changeover relay or a knife switch connected in the antenna leads.

For further information regarding antennas, refer to the *Radio Amateur's Handbook* or the *A.R.R.L. Antenna Book*, both published by the American Radio Relay League, West Hartford, Connecticut, U.S.A.

#### 2.4. POWER SOURCE.

The receiver is designed to operate directly on 105 to 125 volt, 50/60 cycle AC current. Insert the power cord into any convenient AC power outlet of the proper rating. If in doubt about your power source, contact your local power company before connecting power to your receiver. The wrong power source can cause serious damage.


#### 2.5. SPEAKER.

A three-terminal strip, marked GND, STDBY, and 3.2SPKR, is provided at the rear of the receiver for connecting the external speaker that is required with the receiver. (See figure 4.) Any permanent-magnet speaker with a 3.2-ohm voice coil can be used by simply connecting the two leads from the speaker voice coil to the terminals marked 3.2SPKR and GND.

Hallcrafters' Model R-48A Speaker is designed for use with this receiver and may be connected to the terminals marked 3.2SPKR and GND.

#### 2.6. HEADPHONES.

The headphone jack, marked PHONES, is located on the front panel of the receiver and is wired so that the speaker is automatically silenced when the headphones are plugged in. The headphone impedance is not critical and any headphones ranging from 50 ohms to 5000 ohms will provide satisfactory performance.



156-001958

Figure 4. Rear View of Receiver.




Figure 5. Remote Receive-Standby Circuitry.

## 2-7 REMOTE RECEIVE-STANDBY SWITCH.

The receiver may be disabled from a remote location by connecting a remote SPST switch or relay between the STDBY and GND terminals located at the rear of the receiver. (See figure 5.) To operate the receiver with the remote switch, the jumper link must be removed. The switch or relay should be so wired that the contacts will be closed in Receive and open in Standby.

# SECTION III FUNCTIONS OF OPERATING CONTROLS

## 3-1 GENERAL.

The controls discussed in this section are identified in figure 6. Before operating your receiver take time to familiarize yourself with these controls, their positions on the panel, and their functions.

## 3-2. RF GAIN.

The RF GAIN control varies the gain of the RF amplifier and 50-KC IF amplifier stages. Maximum sensitivity is obtained with the control set at 10 (fully clockwise). In this position, the tubes being controlled are operated at maximum gain with minimum cathode bias. As the control is rotated counterclockwise, the bias on the tubes increases with a resultant decrease in gain.

## 3-3. BAND SELECTOR.

The BAND SELECTOR control operates the band switch to place the proper set of coils into the circuit to cover the desired frequency range. The frequency range covered by each position of the BAND SELECTOR control is indicated directly on the panel.

## 3-4. ANTENNA TRIMMER.

The ANTENNA trimmer control operates a variable capacitor connected across the secondary of the antenna coil in use. This capacitor adjustment compensates for the loading effects of various types of antennas.

It should be noted that the ANTENNA trimmer peak will appear broad as the receiver is tuned towards the low-frequency end of the dial and may not give a definite peak. This is a normal condition and does not indicate improper alignment.




Figure 6. Front Panel Controls.

### 3-5. AUDIO GAIN.

The AUDIO GAIN control adjusts the audio level at the speaker terminals and PHONES jack. Clockwise rotation of the control increases the signal applied to the grid of the audio amplifier tube, thus increasing receiver volume; counterclockwise rotation decreases volume.

### 3-6. NOISE LIMITER (ANL-OFF).

The ANL-OFF switch, when set at ANL, places the automatic series noise limiter circuit in operation to reduce pulse-type noise such as ignition noise and electrical interference. The limiter circuit allows the signal to pass unaffected through the receiver, but makes the receiver inoperative for noise amplitudes greater than those of the signal. It will work on AM signals only and is self-adjusting (i.e., it automatically adjusts itself to the signal level).

The noise limiter circuit *chops* noise peaks received at the detector by means of a biased diode which becomes non-conducting above a predetermined signal level. When the limiter circuit is in operation, the audio output of the detector must pass through the limiter diode to the grid of the audio amplifier. The limiter diode normally acts as a conductor for the audio signal as long as the anode is positive with respect to its cathode. When a noise peak is higher in amplitude than the signal, it instantaneously swings the cathode positive with respect to the anode, conduction ceases, and that portion of the signal is automatically cut off from the audio amplifier.

### 3-7. FUNCTION.

The FUNCTION switch performs the following functions:

1. Operates the AC ON/OFF switch.
2. Connects the AM detector to the audio amplifier and disables the BFO.
3. Connects the product detector to the audio amplifier, energizes the BFO and switches in the slow release AVC components.

### 3-8. SELECTIVITY.

The SELECTIVITY control is used to vary the selectivity of the receiver to fit receiving conditions. Three degrees of selectivity are available: 0.5 KC for CW reception under crowded-band conditions, 2.5 KC for SSB, and 5 KC for maximum fidelity during AM reception. The three selectivity positions are shown on the front panel adjacent to the SELECTIVITY control and indicate receiver selectivity at 6 DB down.




Figure 7. IF Selectivity Curves.

092-016760

The receiver IF selectivity curves are shown in figure 7. Note that as the selectivity is varied from a sharp to a broader position, the IF passband not only increases but also shifts to a slightly higher frequency.

It should be noted that two meter peaks will appear when tuning a signal with the SELECTIVITY control in the 5 (KC) position. The signal should be tuned in with the SELECTIVITY at 2.5 (KC) and then switched to the 5 (KC) position if desired.

For broadcast reception, the SELECTIVITY control is normally set at 5, the position affording broadest selectivity. Selectivity may be progressively increased by turning the control to the positions marked 2.5 and 0.5. For reception of the crowded short-wave bands, it is generally advisable to sacrifice fidelity for greater selectivity, since the added selectivity reduces both adjacent-channel interference and background noise by attenuating

the higher audio frequencies. Too much selectivity on AM signals, however, will attenuate the high audio frequencies to such an extent that the signal may become unintelligible as a result of excessive sideband cutting. When receiving CW signals, the sharpest selectivity position (0.5) may be used without the loss of intelligibility experienced in AM reception.

### 3-9. BEAT FREQUENCY OSCILLATOR (BFO).

The BFO is an inductively-tuned oscillator which re-inserts the carrier at the product detector for SSB or CW reception. The center frequency of the BFO is 50.85 KC and is variable over a range of  $\pm 2$  KC.

Placing the BFO frequency on the high-frequency slope of the IF passband allows frequencies below the BFO frequency to be accepted through the IF passband (lower-sideband reception).

Placing the BFO frequency on the low-frequency slope of the IF passband allows frequencies higher than the BFO frequency to be accepted through the IF passband (upper-sideband reception).

The correct settings for USB, LSB, and CW are shown on the panel. It should be noted that changing the BFO setting will affect receiver tuning. Therefore, the bandspread dial should be calibrated with the BFO control preset to the desired position.

The BFO control makes an excellent *fine tuning* control and will be found very useful as such for both CW and SSB reception under crowded conditions.

### 3-10. CALIBRATE (CAL-OFF).

The CAL-OFF switch controls the operation of the optional Model HA-7 Crystal Calibrator. When the switch is set at CAL, the crystal calibrator is turned on to provide marker signals at every 100 KC on the dial. The crystal calibrator employs a crystal-controlled, pentode oscillator circuit. The output of the crystal calibrator is capacitively coupled to the antenna input circuit. A trimmer capacitor, adjustable by the *Crystal Adj.* control on the top of the calibrator unit, permits adjustment of the calibrating crystal to exactly 100 KC by comparison with the frequencies transmitted by WWV. This capacitor has been set at the factory and normally should not require readjustment unless extreme calibration accuracy is required. If adjustment is required, proceed as outlined in paragraph 4-7.

#### NOTE

If the HA-7 calibrator is not used, the CAL-OFF switch should be left in the OFF position at all times.

### 3-11. TUNING AND BANDSPREAD.

The TUNING and BANDSPREAD controls are used in conjunction with one another to tune-in the desired signal. *Coarse tuning* is performed with the TUNING control and *fine tuning* with the BANDSPREAD control.

#### A. MAIN TUNING DIAL

The main-tuning or left-hand dial is operated by the TUNING control. This dial has five calibrated scales, one for each of the four frequency bands plus a logging scale. For normal tuning, the main-tuning dial is set for the desired station frequency after the BANDSPREAD control has been positioned at the *Bandspread Set* line.

#### IMPORTANT

The readings on the main tuning dial will correspond to the station frequencies only if the BANDSPREAD control is set at the *Bandspread Set* line. If it is set at any other position, the additional bandspread capacity added to the main tuning capacity will mis-calibrate the main tuning dial.

The dial settings for the 80, 40, 20, 15, and 10 meter band, which includes the citizens band (26.965 to 27.255 MC), are indicated on the main tuning dial by small circle dots. When tuning with the bandspread dial, the main-tuning dial must be set at the dot corresponding to the desired band. International short-wave broadcast bands are indicated by a double line and identified in meters.

#### B. BANDSPREAD DIAL

The bandspread or right-hand dial is operated by the BANDSPREAD control. This dial contains five scales calibrated for the 80, 40, 20, 15, 10 meter and citizens bands. These five scales are calibrated to read receiver frequency directly when the main-tuning dial has been set to the index dot of the desired band. For convenience in tuning, the amateur bands are indicated on the bandspread dial by double weight lines and the phone bands are indicated by triple-weight lines.

#### NOTE

Use 10-meter dot for citizens-band calibration.

The bandspread dial may also be utilized as a *fine tuning* adjustment over any portion of the receiver tuning range. Two methods of fine tuning are described on the next page.

- a. The first method of fine tuning is used when it is desired to tune in a single signal with precision accuracy. First the BANDSPREAD control is set a few degrees from its *Bandspread Set* position, the desired signal is located with the TUNING control, and then the signal is accurately tuned in by *rocking* the BANDSPREAD control (turning it slightly to the left and right) until the signal is loudest and clearest.
- b. The second method of fine tuning is used when it is desired to tune through a range of frequencies, such as a group of short-wave stations. Set the BANDSPREAD control fully counterclockwise, set the TUNING control for the high end of the selected range of frequencies, and then tune through the range with the BANDSPREAD control. Turning the BANDSPREAD control clockwise tunes the receiver progressively lower in frequency.

## SECTION IV OPERATION

### 4-1. AM RECEPTION.

1. Set the front panel controls to their starting positions as outlined below.

RF GAIN ..... 10 (*maximum sensitivity*).

BAND SELECTOR ..... *At the desired band.*

AUDIO GAIN ..... 2.

ANTENNA ..... *Peak on signal.*

ANL-OFF ..... OFF.

FUNCTION ..... OFF.

SELECTIVITY ..... 2.5 or 5.

CAL-OFF ..... OFF.

2. Turn the receiver on by rotating the FUNCTION control clockwise to AM. The tuning dials will light up, indicating the receiver is operative. Rotate the AUDIO GAIN control clockwise for the desired volume level.
3. Set the bandspread-tuning gang near minimum capacity by rotating the BANDSPREAD control to *Bandspread Set*. To utilize the BANDSPREAD control as a *fine tuning* adjustment for the short-wave bands, refer to paragraph 3-11.

### IMPORTANT

The calibration on the main-tuning (left-hand) dial will be correct only if the bandspread-tuning gang is set at *Bandspread Set*. If it is set at any other position, the additional bandspread capacity added to the main-tuning capacity will mis-calibrate the main-tuning dial.

4. Tune to the desired signal with the TUNING control, tuning for maximum clarity. After the signal has been accurately tuned in, readjust the AUDIO GAIN control as desired.

### NOTE

The *S meter* will not give a true indication of the IF selectivity because the AVC bandwidth is approximately twice as wide as the signal bandwidth at the detector.

When tuning an AM signal, it will be found convenient to tune the signal with the SELECTIVITY set at 2.5 and then turn the SELECTIVITY control to 5 after tuning in the station.

5. Set the SELECTIVITY control for the desired degree of selectivity. For standard-broadcast reception (Band 1), the control is normally set to 5 for maximum fidelity. The positions marked 2.5 and 0.5 provide progressively increasing steps of selectivity. Note that as the selectivity of the receiver is increased, the background noise and interference from adjacent signals is reduced. Too much selectivity, however, may cause excessive sideband cutting. While sideband cutting reduces fidelity, it may frequently be preferable to sacrifice naturalness of reproduction in favor of communications effectiveness. When changing the position of the SELECTIVITY control from a broad to a narrower response, a slight readjustment of the tuning controls may be necessary to center the signal in the IF passband.
6. Use ANL (noise limiter) as noise conditions dictate.

### 4-2. EXALTED CARRIER AM RECEPTION.

In short-wave reception, transmission conditions frequently are different for waves of slightly different frequencies. In voice modulated transmissions (particularly AM), which involve sideband frequencies differing slightly from the carrier frequency, the carrier and sideband components may not be received in the same relative amplitudes and phases that were present at the transmitter. This effect, known as *selective fading*, causes severe distortion of the signal.



Controls should be set as for SSB reception.  
Either USB or LSB may be used.

1. Set the front panel controls to their starting positions as follows:

BANDSPREAD . . . . . As desired.

It should be remembered that an SSB signal will convey intelligence only when the correct sideband position has been selected by the BFO control. If the signal does not tune properly, move the BFO control to the opposite sideband position and retune the receiver.

Set all controls as shown in single-sideband reception except for the BFO control which should be set to the CW position.

The optional Model HA-7 100-KC Crystal Calibrator permits accurate checking of the dial calibration over any portion of the main and bandspread tuning dials by comparing the dial calibrations with the marker signals which appear at every multiple of 100 KC on the dial.

5. The procedure outlined in Steps 1 through 4 above provides average calibration accuracy over the entire frequency range of the band in use. For precise calibration accuracy over a particular section of the band, the procedure is identical except that the band-spread dial is set at a multiple of 100 KC near the desired frequency or range of frequencies, instead of at the high end of the band as in Step 1.

2. Set the main-tuning dial at a convenient multiple of 100 KC near the desired frequency or range of frequencies. (The main-tuning dial is calibrated in MC.) To determine the nearest 100 KC multiple, simply remember that 100 KC is equal to 0.1 MC. For example, from 2.0 to 3.0 MC on band 2, the 100-KC multiples are 2.0 MC, 2.1 MC, 2.2 MC, 2.3 MC, etc.

3. Set the **FUNCTION** switch to **SSB/CW**. Then set the **CAL-OFF** switch to **CAL**. If a *zero beat* does not occur at the **100-KC** check point, turn the **BANDSPREAD** control clockwise or counterclockwise as necessary to establish Main-Tuning dial calibration.

#### 4-6. USE OF THE *S* METER.

The *S meter* provides a visual means of determining whether or not the receiver is properly tuned, as well as an indication of the relative signal strength. The *S meter* circuit consists of a DC milliammeter connected in series with the cathode lead to the 1650-KC IF amplifier tube, the grid of which is controlled by AVC voltage. Since the cathode current of this tube varies with the strength of the incoming signal, the meter will indicate relative signal strength. The *S meter* is calibrated in *S* units from 1 to 9 and in decibels above S-9. The indications on the *S meter* will be correct only when the **RF GAIN** control is set at 10 (maximum sensitivity).

#### NOTE

If the **RF GAIN** control is set at a reduced position, the *S meter* may read below zero under no signal conditions. This is a normal condition.

#### 4-7. CRYSTAL CALIBRATOR CHECK.

The *Crystal Adj.* control on the optional Model HA-7 Calibrator chassis operates a trimmer capacitor connected across the 100-KC calibrating crystal. This trimmer capacitor permits adjustment of the calibrating crystal at exactly 100 KC by comparison with the frequencies transmitted by station WWV. This capacitor has been set at the factory and should not require readjustment unless extreme calibration accuracy is desired. If adjustment is required, proceed as follows:

Set the **FUNCTION** switch to **AM**, the **CAL-OFF** switch to **OFF**, and all other front-panel controls for normal **AM** reception. Tune in station WWV on any one of its operating frequencies (2.5, 5, 10, 15, 20, or 25 MC) and wait for the period during which the signal from WWV is unmodulated. Then switch on

the crystal calibrator by setting the **CAL-OFF** switch to **CAL** and adjust its frequency, by means of the *Crystal Adj.* control, until the crystal calibrator signal *zero beats* with the signal received from WWV. If the adjustment is attempted during periods that WWV is modulated, an erroneous *zero beat* may be obtained with the modulating frequency instead of the desired carrier frequency.


#### 4-8. OPERATING AND SERVICE QUESTIONS.

For further information regarding operation or servicing of this equipment, contact the dealer from whom the unit was purchased. The Hallicrafters Company maintains an extensive system of Authorized Service Centers where any required service will be performed promptly and efficiently at no charge if this equipment is delivered to the service center within 90 days from date of purchase by the original buyer and the defect falls within the terms of the warranty. It is necessary to present the *Bill-of-Sale* in order to establish warranty status. After the expiration of the warranty, repairs will be made for a nominal charge. All Hallicrafters Authorized Service Centers display the sign shown below. For the location of the one nearest you, consult your dealer or your local telephone directory.

Make no service shipments to the factory unless instructed to do so by letter, as The Hallicrafters Company will not accept responsibility for unauthorized shipments.

The Hallicrafters Company reserves the privilege of making revisions in current production of equipment and assumes no obligation to incorporate such revisions in earlier models.





## SECTION V

### ALIGNMENT

This receiver has been carefully aligned at the factory by specially-trained personnel using precision equipment. Alignment of the receiver should not be attempted until all other possible causes of faulty operation have been investigated. Alignment should not be required unless the receiver has been tampered with or component parts have been replaced in the RF or IF stages. Alignment should be performed only by persons familiar with communications receivers and experienced in their alignment. Refer to figures 8 and 9 for location of all alignment adjustments.

#### 5-1. EQUIPMENT REQUIRED.

Signal generator covering 50 KC to 30 MC.  
Vacuum tube voltmeter (VTVM) or other high-impedance DC voltmeter.

Output meter (or AC scale of VTVM). Connect output meter to appropriate speaker output terminals. If a VTVM is used, connect it to terminals 3.2 SPKR and GND and terminate the output with a dummy load.

#### 5-2. INITIAL CONTROL SETTINGS.

Band Selector . . . . . As indicated in chart.

RF and AUDIO GAIN . . . . . 10 (maximum).

ANL - OFF . . . . . OFF.

FUNCTION . . . . . AM.

Selectivity . . . . . As indicated in chart.

Tuning and Bandsread . . . . . Gangs half meshed.

#### 5-3. ALIGNMENT PROCEDURE.

STEP	SIGNAL GENERATOR CONNECTIONS	SIGNAL GENERATOR FREQUENCY	BAND SELECTOR SETTING	OUTPUT CONNECTIONS	SELECTIVITY SETTING	REMARKS
<b>50-KC IF ALIGNMENT</b>						
1	High side to alignment point A (terminal 2 of T2). Low side to chassis.	50 KC (unmod)	0.540 to 1.60 MC	VTVM DC probe to alignment point B (junction of R55, R56, and C84). Common to chassis.	0.5 KC	Remove first conversion oscillator tube V3 from its socket to prevent signal interference. Adjust top slug of T6, T5, T4, and T3 (50-KC IF's) for maximum indication, maintaining approximately one volt reading on VTVM.
<b>1650-KC IF ALIGNMENT</b>						
2	High side to alignment point C (stator of section C3B of main tuning gang). Low side to frame of gang.	1650 KC (mod)	0.540 to 1.60 MC	Output meter across speaker terminals (VTVM to alignment point B if it is desired to monitor detector voltage.)	5 KC	Replace tube removed in Step 1. Tune generator slowly through 1650 KC to determine IF passband. Then set generator to center of passband, using sufficient generator output to obtain approximately 1/2 watt receiver output and adjust the top and bottom slugs of T2 and T1 for maximum response. Tune through the passband and observe the shape of the response. If it is symmetrical, the adjustment is completed; if not, reset the generator frequency near the center of the passband and re-peak T2 and T1.
<b>IF SENSITIVITY CHECK</b>						
3	With the generator modulated 30% at 400 cycles and connected through a 0.05 $\mu$ F capacitor to the grid (pin 1) of the first mixer tube V2, the IF input required for 1/2-watt receiver output should be approximately 15 microvolts (1650 KC).					




Figure 9. Bottom Chassis View.

## RF ALIGNMENT

Before proceeding with the RF alignment, check the tuning dials for proper indexing. Both dials should index on the marks at the low-frequency end with the gang fully closed.

Use an amplitude-modulated signal.

Set the RF and AUDIO GAIN to 10 (maximum), ANL - OFF to OFF, SELECTIVITY to 2.5, FUNCTION to AM, and BANDSPREAD at *Bandspread Set*.

Connect the output meter across the speaker terminals. (Connect the VTVM to alignment point B if it is desired to monitor the detector voltage.) Maintain a 1/2-watt receiver output.

Connect high side of generator through a 330-ohm carbon resistor to antenna terminal A1, low side to A2. Connect jumper between A2 and GND.

The oscillator frequency is higher than the signal frequency on all bands.

STEP	BAND SELECTOR SETTING	GENERATOR AND RECEIVER FREQUENCY	ADJUST FOR MAXIMUM
4	12.5 to 34 MC	30.0 MC	C59 (oscillator trimmer), C50 (mixer trimmer), and C2 (antenna trimmer)
	12.5 to 34 MC	14.0 MC	L12 (oscillator slug) L8 (mixer slug), and L4 (antenna slug)
5	4.8 to 12.6 MC	11.5 MC	C60 (oscillator trimmer), C49 (mixer trimmer), and C2 (antenna trimmer)
	4.8 to 12.6 MC	5.0 MC	L11 (oscillator slug), L7 (mixer slug), and L3 (antenna slug)
6	1.75 to 4.9 MC	4.6 MC	C61 (oscillator trimmer), C48 (mixer trimmer), and C2 (antenna trimmer)
	1.75 to 4.9 MC	2.0 MC	L10 (oscillator slug)
7	0.54 to 1.60 MC	1.4 MC	C62 (oscillator trimmer), C47 (mixer trimmer), and C2 (antenna trimmer)
	0.54 to 1.60 MC	0.6 MC	C71 (oscillator padder)

### 5-4. S METER CALIBRATION.

1. To adjust the *Meter Zero* the antenna should be disconnected and the receiver antenna terminals shorted; RF GAIN full on.

Adjust the *Meter Zero* potentiometer (R16) on the rear apron of the chassis until the meter pointer is directly over the last calibration mark on the left side of the meter scale. With this adjustment made, if the RF GAIN is rotated counter-clockwise, the meter may read below zero. This is normal.

### NOTE

Allow at least one-half hour warmup time before making any adjustments.

2. To adjust the meter calibration, it will be necessary to have a signal generator that is accurately calibrated in microvolts output.

- a. Set generator to 14.3 MC and 50 microvolts output.
- b. Place SELECTIVITY switch to the 2.5 position, FUNCTION to AM and carefully tune receiver for maximum *S* meter deflection at 14.3 MC.

- c. Peak ANTENNA trimmer (C2).
- d. If the meter does not read S9, adjust Meter Sensitivity potentiometer (R13) near top center of chassis for S9 reading.
- e. Recheck Meter Zero setting and repeat adjustments if necessary.

#### 5-5. BFO CALIBRATION.

To check the BFO calibration, set the receiver controls for CW reception, SELECTIVITY to 0.5 and tune in an unmodulated signal for maximum S meter deflection. With the BFO control at mid rotation (CW position), the beat-note frequency should be between 700 and 1000 cycles and zero beat should occur with the control rotated approximately forty-five degrees clockwise from the center position.

If the control is far from its correct setting, it may be *roughed in* in the following manner.

1. Remove the BFO knob and the adapter bushing from the BFO tuning shaft.
2. Set receiver controls for CW reception, SELECTIVITY in the 2.5 position and tune receiver to clear frequency (no signal).
3. With screwdriver, run the BFO tuning shaft in or out as necessary to the point where the noise becomes lowest in audio pitch with a symmetrical rise in pitch in either direction from this point. With the shaft set at the point of lowest audio noise pitch, replace the shaft bushing with the long set screw straight up (vertical position).
4. Replace BFO knob with indicator line in CW position (mid rotation).

## SECTION VI SERVICE DATA

#### 6-1. TECHNICAL SPECIFICATIONS.

##### FREQUENCY COVERAGE

BAND	FREQUENCY RANGE	CALIBRATED BANDSPREAD
1	0.540 to 1.60 MC	—
2	1.75 to 4.9 MC	80M
3	4.8 to 12.6 MC	40M
4	12.5 to 34.0 MC	20, 15, 10M, Citizens Band

##### TUBES

Nine plus voltage regulator and rectifier.

##### SPEAKER OUTPUT

3.2 ohms

##### HEADPHONE IMPEDANCE

50 to 5000 ohms.

##### ANTENNA INPUT IMPEDANCE

50 to 600 ohms.

##### POWER SOURCE

105 to 125 volts, 50/60 cycles.

##### POWER CONSUMPTION

85 watts.

##### RECEPTION

AM, CW, and SSB.

##### INTERMEDIATE FREQUENCIES

(Double Conversion): 50 KC and 1650 KC.

##### DIMENSIONS (overall) (HWD)

8 by 18-3/4 by 9-13/16 inches (HWD).

##### SHIPPING WEIGHT

32-1/2 pounds.

##### NET WEIGHT

28-3/4 pounds.

#### 6-2. 50-KC-IF SYSTEM.

Figure 10 shows the type of coupling used in the 50-KC IF system. Note that inductive coupling is avoided by careful shielding of the IF coils and signal transfer occurs only through capacity and resistance. By increasing the value of R (resistance) and decreasing C (capacity), the selectivity is made broader; while decreasing R and increasing C causes the selectivity to become sharper. The proper values of C and R are switched in the circuit by means of the SELECTIVITY control. R varies the Q of the tuned circuit and C varies the coupling. This R-C coupling arrangement affords a more accurate means of selectivity control than that readily obtainable by any other method.

#### 6-3. CHASSIS REMOVAL.

Both the top and bottom covers can be removed for easy access to both sides of the chassis. To remove the chassis and panel assembly from the cabinet, remove the four outer bottom screws and slide chassis forward through front of cabinet.




Figure 10. Equivalent Schematic Diagram of 50-KC IF System.

156-001905

### IMPORTANT

To remove the top cover, turn the four screws counterclockwise one quarter turn and lift cover. Do not attempt to remove these screws.

To remove the bottom cover, remove the four inner bottom screws.

#### 6-4. TUBE AND DIAL LAMP REPLACEMENT.

To gain access to the tubes and dial lamps, remove top cover (see IMPORTANT note above). See label on the inside rear of cabinet for tube location.

#### 6-5. DIAL RESTRINGING.

The bandspread gang restringing (figure 11) may be accomplished without removing any parts. Before starting, attach the tension springs to the cable, rotate the BANDSPREAD control knob fully clockwise, and set the bandspread gang in its closed position. Attach the spring at one end of the cable to position 1 on the pulley as shown in figure 11 and follow the stringing sequence 1 through 9.

After stringing, check to see if the dial scale lines up with the pointer when the bandspread gang is in its closed position. If the index marks on the scale do not line up, loosen the set screws holding the dial to the shaft and rotate to proper position.




Figure 11. Restringing the Bandspread Gang.

156-001841






Figure 12. Restringing the Main Tuning and Bandspread Dials.

156-001840

In order to restring the dial drive of either the main tuning or bandspread dial, the front panel, pointer, and dial scale should be taken off for accessibility. In both drives the gang is set in its closed position. Attach the knotted end of the string to position 1 on the pulley as shown in figure 12 and follow the stringing sequence 1 through 7.

#### 6-6. VOLTAGE AND RESISTANCE MEASUREMENTS.

The voltages normally present at the pins of the various tubes within this receiver are shown in figure 14. The resistances present at these same pins are shown in figure 15. To identify the tube elements by pin number, refer to figure 18, the schematic diagram.




Figure 13. Block Diagram of the Model SX-122 Receiver.

156-001638




Figure 14. Voltage Chart of Receiver.

156-001745



## SECTION VII 100-KC CRYSTAL CALIBRATOR MODEL HA-7




Figure 16 Model HA-7 100 KC Crystal Calibrator. (156 10020 1)

### 7.1. GENERAL

The Model HA-7 100-KC Crystal Calibrator is a precision-built accessory which provides marker signals at every 100 KC on the dial of the SX-122 enabling the operator to check calibration accuracy. The HA-7 is placed into operation by plugging it into the appropriate socket (J1) on the receiver chassis (see Figure 8) and placing the front panel (M OFF) switch in the (M) position (refer to paragraph 3-10).

### IMPORTANT

The (M OFF) switch should be returned to the OFF position after calibration to prevent spurious signal generation.

### 7.2. ADJUSTMENT.

A trimmer capacitor, adjustable by the Crystal Adj control on the top of the calibrator unit, permits adjustment of the calibrating crystal to exactly 100 KC by comparison with the frequencies transmitted by station WWV. This capacitor has been set at the factory and normally should not require readjustment unless extreme calibration accuracy is required. If adjustment should be necessary, proceed as outlined in paragraph 4-7 of this document.

### PARTS LIST

SCHEMATIC SYMBOL	DESCRIPTION	HALLICRAFTERS PART NUMBER
	100-KC Crystal Calibrator Assembly (Model HA-7)	001-004394
C301	Capacitor, Variable, 8 to 50 $\mu\mu$ F, Crystal Adj.	044-20043
C302,304	Capacitor, 0.01 $\mu$ F, 500V, Ceramic Disc	047-100224
C303	Capacitor, 82 $\mu\mu$ F, 10%, Mica	470-213820
CR301	Diode, Type 1N295	019-301980
P301	Plug, 5-Pin (Connects to J1 on SX-122)	035-100038
R301,304	Resistor, 220K Ohms, 10%, 1/2 watt, Carbon	451-252224
R302	Resistor, 4700 Ohms, 10%, 1/2 watt, Carbon	451-252472
R303	Resistor, 100K Ohms, 10%, 1/2 watt, Carbon	451-252104
V301	Electron Tube, Type 6AU6	090-900808
Y301	Crystal, 100-KC Marker	019-202351
	Shield, Cover	069-001719
	Socket, Crystal (Y301)	006-200296
	Socket, Tube (V301)	006-100759




20.

## SERVICE REPAIR PARTS LIST

SCHEMATIC SYMBOL	DESCRIPTION	HALLICRAFTERS PART NUMBER	SCHEMATIC SYMBOL	DESCRIPTION	HALLICRAFTERS PART NUMBER	SCHEMATIC SYMBOL
CAPACITORS			* RESISTORS			ELECTRONIC SYMBOL
C1, 25, 33, 42, 45, 52	2.2 $\mu$ F, 10%, 500V, Composition	047-200403-04	R1, 26, 56	1 Megohm	451-252105	V9
C2	Variable, 4.6 $\mu$ F to 57 $\mu$ F, ANTENNA Trimmer	048-000546	R2	22 Ohms	451-252220	V10
C3A, B, & C	Variable, TUNING	048-000547	R3, 7, 14	15 Ohms	451-252150	V11
C4, 43, 85	220 $\mu$ F, 5%, 500V, Plastic Mica	493-110221-234	R4	180 Ohms	451-252181	CR1
C5, 18, 21, 26, 28, 34, 40, 82	0.02 $\mu$ F, +80%, -20%, 500V, Ceramic Disc	047-100242	R5, 17	33K Ohms, 1 watt	451-352333	
C6, 9, 10, 11, 12, 44, 76, 93	0.005 $\mu$ F, +80%, -20%, 500V, Ceramic Disc	047-101381	R6, 12, 22	100K Ohms	451-252104	
C7, 8, 35	10 $\mu$ F, 5%, 500V, Plastic Mica	493-110100-231	R7	2.2 Megohms	451-252225	S1
C8, 15, 22, 84, 92, 95	0.01 $\mu$ F, +80%, -20%, 500V, Ceramic Disc	047-100217	R8, 23	2200 Ohms	451-252222	S1A
C9, 14, 29, 39, 41, 94	0.1 $\mu$ F, +80%, -20%, 50V, Ceramic Disc	047-001146	R9, 47, 48, 50, 62	220K Ohms	451-252224	S1B
C16, 30	100 $\mu$ F, 5%, 500V, Plastic Mica	493-110101-234	R10, 47, 48, 50, 62	220K Ohms	451-252224	S1C
C17	47 $\mu$ F, 5%, 500V, Plastic Mica	493-110470-233	R11, 29, 38, 39	3300 Ohms	451-252332	S1D
C19	20 $\mu$ F, 5%, 500V, Plastic Mica	493-110200-231	R13	Variable, 2 Megohms, 30%, 1/4 watt, Meter Sensitivity	025-001957	S2
C20	120 $\mu$ F, 5%, 500V, Plastic Mica	493-110121-234	R15	150 Ohms	451-252151	S3
C23, 24, 31, 32	390 $\mu$ F, 5%, 500V, Plastic Mica	493-110391-234	R16	Variable, 400 Ohms, 30%, 1 watt, Meter Zero	451-252152	S4
C27, 37, 80, 81, 83, 90, 91, 98	0.001 $\mu$ F, 20%, 500V, Ceramic Disc	047-101671	R18	120K Ohms	451-252172	S5
C36	330 $\mu$ F, 5%, 500V, Plastic Mica	493-110331-234	R19, 48	1500 Ohms	451-252472	
C38	1000 $\mu$ F, 5%, 500V, Plastic Mica	493-310102-234	R20	4700 Ohms	451-252233	
C46, 54	25 $\mu$ F, 10%, N750, Ceramic Tubular	491-008250-95	R21, 28, 41, 45	22K Ohms	451-652473	
C47	Variable, Trimmer, 1.5 $\mu$ F to 15 $\mu$ F	044-100399	R24	47K Ohms, 2 watts	451-352223	
C48, 49, 62	Variable, Trimmer, 3 $\mu$ F to 30 $\mu$ F	044-100396	R25	22K Ohms, 1 watt	451-352201	
C50	Variable, Trimmer, 4 $\mu$ F to 80 $\mu$ F	044-100395	R27	100 Ohms	451-252101	
C51A & B	Variable, BANDSPREAD	048-000548	R30, 32	47K Ohms	451-252473	
C53, 74	100 $\mu$ F, 10%, N750, Ceramic Tubular	491-026101-94	R33	330 Ohms	451-252331	Y1
C55	7 $\mu$ F, $\pm 0.25$ $\mu$ F, N1500, Ceramic	479-011070	R34	68K Ohms	451-252893	
C56, 58	5 $\mu$ F, $\pm 0.25$ $\mu$ F, N3300, Ceramic	479-031050	R37	6800 Ohms, 1 watt	451-352882	
C57	11 $\mu$ F, 5%, N1500, Ceramic	479-015110	R40	3300 Ohms, 1 watt	451-352332	
C59	Variable, Trimmer, 4.5 $\mu$ F to 25 $\mu$ F, NPO	044-200453	R42	10K Ohms, 1 watt	451-352103	
C60	Variable, Trimmer, 2.5 $\mu$ F to 15 $\mu$ F, NPO	044-200452	R43	6K Ohms, 5 watts, wire wound	445-012602	
C61	Variable, Trimmer, 4.5 $\mu$ F to 25 $\mu$ F, NPO	044-200451	R44	10K Ohms	451-252103	
C63	1000 $\mu$ F, 5%, 500V, N2200, Ceramic	047-200441	R46	3.9 Megohms	451-252395	
C64	1300 $\mu$ F, 5%, 500V, Plastic Mica	493-310132-234	R51, 53	220 Ohms	451-252221	
C65	100 $\mu$ F, 10%, NPO, Ceramic Tubular	491-056101-22	R52, 54	390 Ohms	451-252391	
C66	680 $\mu$ F, 5%, 500V, Plastic Mica	493-310881-234	R55	820K Ohms	451-252824	
C67	320 $\mu$ F, 5%, N750, Ceramic Tubular	491-065321-94	R57	180K Ohms	451-252184	F1
C68	10 $\mu$ F, 10%, NPO, Ceramic Tubular	491-006105-22	R59	10 Megohms	451-252106	
C69	240 $\mu$ F, 5%, 500V, Plastic Mica	493-110241-234	R60	Variable, 500K Ohms, 30%, 1/8 watt, AUDIO GAIN	025-002254	J2
C70	220 $\mu$ F, 5%, N330, Ceramic Tubular	491-085221-73	R81	15 Megohms	451-252158	
C71	Variable, Trimmer, 116 $\mu$ F to 160 $\mu$ F	044-100398	R83	880K Ohms	451-252684	
C72	10 $\mu$ F, $\pm 0.5$ $\mu$ F, N3300, Ceramic	479-032100	R84	150 Ohms, 1 watt	451-352151	
C73	1.0 $\mu$ F, $\pm 0.1$ $\mu$ F, N2200, Ceramic	479-220010	R85	Variable, 10K Ohms, 20%, 1 watt, HF GAIN	025-002253	
C75	1.0 $\mu$ F, 10%, N750, Ceramic Tubular	491-006010-94	R86	330K Ohms	451-252334	
C77	12 $\mu$ F, 250V, Electrolytic	045-001121	R87	47 Ohms, 1 watt	451-352470	
C78, 87	4700 $\mu$ F, 5%, 400V, Paper Tubular	046-001132-03	R88	300 Ohms, 5 watts, wire wound	445-012301	
C79, 88	0.01 $\mu$ F, 5%, 400V, Paper Tubular	046-001316-03	R89	1500 Ohms, 5 watts, wire wound	445-012152	M1
C86, 96	470 $\mu$ F, 5%, 500V, Plastic Mica	493-110471-234	* All Resistors are carbon type, 10%, 1/2 watt, unless otherwise specified.			DS1, 2, 3
C89	0.47 $\mu$ F, 10%, 200V, Paper Tubular	046-001302-04	COILS AND TRANSFORMERS			
C97	10 $\mu$ F, 25V, Electrolytic	045-000934	L1	Coil, Antenna, Band 1	050-000952	
C99	60 $\mu$ F, 450V; 20 $\mu$ F, 450V; 20 $\mu$ F, 400V; Electrolytic	045-200113	L2	Coil, Antenna, Band 2	050-000952	
C100	5 $\mu$ F, 5%, 500V, Plastic Mica	493-110050-231	L3	Coil, Antenna, Band 3	050-000954	J1
			L4	Coil, Antenna, Band 4	050-000955	
			L5	Coil, BFO	054-000059	
			L6	Coil, Mixer, Bands 1 and 2	051-201319	
			L7	Coil, Mixer, Band 3	051-201326	
			L8	Coil, Mixer, Band 4	051-201327	
			L9	Coil, Oscillator, Band 1	051-201328	
			L10	Coil, Oscillator, Band 2	051-201921	
			L11	Coil, Oscillator, Band 3	051-201933	
			L12	Coil, Oscillator, Band 4	051-201321	
			T1, 2	Transformer, 1650-KC IF	050-000788	
			T3, 4, 5, 6	Transformer, 50-KC IF	050-200489	
			T7	Transformer, Output	055-000519	
			T8	Transformer, Power	052-300221	
			ELECTRON TUBES AND DIODES			
			V1, 4	Tube, Type 6DC6	090-901328	
			V2	Tube, Type 6AU6	090-200808	
			V3	Tube, Type 6C4	090-900830	
			V5	Tube, Type 6BL8	090-901350	TB1, 2
			V6	Tube, Type 6BA6	090-901112	
			V7	Tube, Type 6BE6	090-901124	
			V8	Tube, Type 6BN8	090-001465	

# IST

HALLICRAFTERS PART NUMBER	SCHEMATIC SYMBOL	DESCRIPTION	HALLICRAFTERS PART NUMBER
ELECTRON TUBES AND DIODES (CONT)			
451-252105	V9	Tube, Type 6GW8	090-001502
451-252220	V10	Tube, Type 6Y3GT	090-901111
451-252150	V11	Tube, Type OA2	090-900001
451-252181	CR1	Diode, Type 1N456	019-002984
451-352333			
REMOVED JUMP			
451-252104			
SWITCHES			
451-252225	S1	Rotary, BAND SELECTOR	-----
451-252222	S1A	Wafer, Oscillator	062-200055
451-252222	S1B	Wafer, Oscillator	062-200054
451-252224	S1C	Wafer, Mixer	062-200053
451-252332	S1D	Wafer, Antenna	062-200053
025-001957	S2	Slide, SPDT, CAL-OFF	060-002548
	S3	Rotary, SELECTIVITY	060-002626
	S4	Rotary, FUNCTION (Inc. ON/OFF)	060-002628
	S5	Slide, SPDT, ANL-OFF	060-002546
MISCELLANEOUS			
451-252124		Bracket, Meter Mounting	067-011850
451-252152		Cabinet	066-004055
451-252472		Cabinet Bottom Assembly	150-006789
451-252223		Cabinet Top Assembly	150-006770
451-852473		Clip, IF Transformer Mounting	076-003779
451-352223		Core, Coil Tuning (L3-4-7-8-10)	077-100088
451-252101		Core, Coil Tuning (L5)	003-103289
451-252473		Core, Coil Tuning (L11)	003-101543
451-252331		Core, Coil Tuning (L12)	077-101336
451-252683		Core, Coil Tuning (I3-4-5-6)	003-101631
451-352682	Y1	Crystal, 1700 KC	019-003231
451-352332		Dial Cord, Bandspread Gang	038-000061
451-352103		Dial Cord, Tuning and Bandspread Dials	038-000049
445-012802		Dial Scale, BANDSPREAD	083-001029
451-252103		Dial Scale, TUNING	083-001030
451-252395		Escutcheon, Front Panel	007-000871
451-252221		Feet, Plastic Mounting	016-201072
451-252391		Flywheel	071-000212-02
451-252824		Front Panel	068-001455
451-252104	F1	Fuse, 2 Ampere, S/B	039-100422
451-252106		Fuse Holder (Inc. Hardware)	006-200645
025-002254		Glass, Dial Window	022-000711
451-252156	J2	Jack, PHONES	036-000350
451-252884		Knob, TUNING	015-001593
451-352151		Knob, RF GAIN, BAND SELEC-	015-001760
025-002253		TOR, ANTENNA, AUDIO GAIN	
451-252334		SELECTIVITY, BFO, and FUNCTION	
NO. 451-352470		Line Cord	087-100078
445-012301		Lock, Line Cord	078-100397
051445-012152		Medallion, Hallicrafters H	007-000850
	M1	Meter, 0-5 MA Deflection	082-000603
	DS1, 2, 3	Pilot Lamp, Type NO. 47	039-100004
		Pointer, BANDSPREAD and TUNING Dials	082-000600
		Shaft and Index Plate, BAND SELECTOR	074-200172
		Shaft, Antenna Trimmer	074-002883
		Shaft, Control, TUNING and BANDSPREAD	074-002878
050-000952	J1	Socket, Accessory (HA-7)	006-100186
050-000953		Socket, Pilot Light (Bandspread Dial)	086-000665-02
050-000954		Socket, Pilot Light (Meter Dial)	086-000666
050-000955		Socket, Pilot Light (Tuning Dial)	086-000665-01
054-000059		Socket, Tube, Octal (V10)	006-200296
051-201319		Socket, Tube, 7-pin miniature (V1-2-4)	006-200633
051-201326		Socket, Tube, 7-pin miniature (V3)	006-001048
051-201327		Socket, Tube, 7-pin miniature (V8-7)	006-000946
051-201328		Socket, Tube, 7-pin miniature (V11)	006-100844
051-201921		Socket, Tube, 9-pin miniature (V5)	006-200672
051-201933		Socket, Tube, 9-pin miniature (V8-9)	006-200493
051-201321		Spring, Dial Cord Tension, Bandspread Gang	075-000139
050-000788		Spring, Dial Cord Tension, Tuning and Bandspread Dials	075-000893
050-200489	TB1, 2	Terminal Board, Antenna and Speaker	088-002461
055-000519		Tube Shield (V1-2-4)	069-000097
052-300221		Tube Shield (V5)	069-000855
090-901328			
090-200806			
090-900830			
090-901350			
090-901112			
090-901124			
090-001455			








Figure 18. Schematic Diagram, Model SX-122 Receiver.

