

TRANSMITTER

(Plug the previously prepared 50 Ω dummy load into	()	Set the LOADING control to the 12 o'clock position.
		the ANTENNA socket on the back of the Transceiver. (This may already be connected to the Transceiver.)	ţ)	Key the Transceiver and adjust trimmer C99 to obtain a maximum reading on the RELATIVE POWER meter.
(ł	Connect the key to the KEY jack on the back of the Transceiver. (This also may already be connected to			
	the Transceiver.)			,	Key the Transceiver and adjust the LOADING control on the front panel to obtain a maximum reading on the RELATIVE POWER meter.
ita	NOTE: Use the alignment tool that you made from the nut starter and blade for all trimmer adjustments. DO NOT use a screwdriver.)	Repeat the previous two steps.
			()	Press the 14.0 MHz pushbutton.
{)	Turn the screws in trimmers C95, C99, C103, and C106 clockwise until they stop turning. Do not force the screws.	()	Set the LOADING control to the 12 o'clock position.
į)	Turn the screw in trimmer C95 1/2 turn counterclockwise.	(Ì	Key the Transceiver and adjust trimmer C103 to obtain a maximum reading on the RELATIVE POWER meter.
)	Turn the screw in trimmer C99 1/8 turn counterclockwise.	()	Key the Transceiver and adjust the LOADING control to obtain a maximum reading on the RELATIVE POWER meter.
)	Turn the screw in trimmer C103 1 turn counterclockwise.	()	Repeat the previous two steps.
)	Turn the screw in trimmer C106 1/4 turn counterclockwise.	()	Press the 21.0 MHz pushbutton.
)	Make sure the TUNING dial is set to 100.	į)	Set the LOADING control to the 12:00 o'clock position.
	}	Press the 3.5 MHz pushbutton.	()	Key the Transceiver and adjust trimmer C106 to
		Set the LOADING control on the front panel to the		•	obtain a maximum reading on the RELATIVE POWER meter.
		12 o'clock position.			
NOTE: In the following steps, the adjustments will be quite proad.			()	to obtain a maximum reading on the RELATIVE
		Key the Transceiver and adjust trimmer C95 for a maximum reading on the RELATIVE POWER meter.			POWER meter.
			()	Repeat the previous two steps.
		Key the Transceiver and adjust the LOADING control			_
		on the front panel to obtain a maximum reading on the RELATIVE POWER meter.	()	Turn the Transceiver off.
;)	Repeat the previous two steps.	()	Disconnect the key and dummy load from the Transceiver.

() Press the 7.0 MHz pushbutton.