SHOOTING'S THREE TIMES MORE FUN

with a

SERIES 150 GAS-POWERED PISTOL

COSMON ARMS CO., INC.

World's largest producer of pellet ritles and pistols

www.muzzle.de

Only (Crosman series iso

 No pumping; powered by one giant Crosman CO₂ Gas Powerlet. Approximately 50 shots at 400 f/p/s average muzzle velocity.

Deluxe, rugged target sights . . . precision-made and

mounted.

 Heavy-duty all-steel barrel with new precision "Button Rifling".

 Blued steel, tenite grip . . . shaped for left or right hand shooters.

Every pistol factory-tested to group shots under ¼" at 25'.

Easy fingertip cocking.

Positive push-type cross-lock safety . . . shows red on "off" position.

 Exclusive solid breech cover gives smooth, easy loading action.

 Carrying distance averages only 200'...ideal for limited area shooting.

Weight, 1 lb., 10 oz.; length. 10".

· Choice of standard calibers:

.177 (Model 157) and .22 (Model 150).

Ask to see the Crosman Model 150 Pistol in the complete, economical Home Shooting Set (Model 150-K).


NO FIREARM PERMIT NEEDED

The Finest

"POWER WITHOUT POWDER"
Pellet Guns Made

www.muzzle.de

www.muzzle.de



GUARANTEE CERTIFICATE BMPORTANT Eeea this certificate. Must be presented to Crosman Authorized Service Station to qualify for warrenty service. Customer's Name Street Tawn Shate Date Purchased [See Over]

www.muzzle.de

List of Parts and Assemblies:

NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
1	150-59	Front Sight Screw	23	150-13	Connecting Screw
2	199-33	Barrel	11		
3	150-58	Front Sight	25	150-6	Piercing Body
4	150-35A		26	111-28	Check Valve Spring
5	150-57	Rear Sight Screw	21	150-9	Ptercing Ptn
6	150-56	Rear Sight	28	150-80	Valve Stem Assembly
7	160-52	Breech Boll Screw	29	150-28	"O" Ring
8	120-29	Breech Gasket	30	150-5	Exhaust Valve
9	130-33	Bolt "O" Ring	91	111-67	Take Up Spring
10	130-20	Breech Bolt	32	105-17	Trigger
11	180-16	Breech Cover	33	150-10	Front Frame Screw
12	150-67	Breech Plag	34	105-35	Trigger Pts
13	150-62	Hammer Assembly	35	105-36	Safety
14	150-18	Small Tube Ping	35 36 37	105-32	Sear Pin
15	130-64	Grip Frame Assembly	37	105-1	Grip Prame
16	150-25	Thrust Pin	38	105-55	Rear Frame Screw
15 16 17	350-1	Tube	39	111-30	Sear Spring
18	150-61	Walse Assembly	40	105-45	Sear Spring Head
19	350-64	Tube Cap Assembly	41	150-16	Sear
20	150-54		42	105-45	Safety Spring
21	150-11	Rest Block	43	105-44	Safety Spring Ball
22	150-12	Tube Cap	11		

www.muzzle.de

Crosman

Authorized Repair Stations

The nationwide network of Authorized Crosman Factory Repair Stations listed hereon has been established for your convenience and in the interest of providing fast local service. All of these stations are fully equipped to handle repairs on all models of Crosman Pellguns, including repairs to guns within guarantee period having malfunctions of a minor nature. Guns having a malfunction of a major nature should be returned to your dealer or direct to the factory at Fairport, N. Y.

The guarantee certificate attached to the instruction sheet that is packed with each Crosman gun should be properly filled out at time of purchase and must accompany your gun when sent to a Service Station for repair during the company's 90-day guarantee service period. In cases where the guarantee certificate has been misplaced a verification (Sales Slip) from your dealer will suffice.

NOTE: Air and CO2 Pistols can only be mailed to and from bona fide dealers and manufacturers and in turn must conform with Postal Laws and regulation requirements at time of mailing. Consult your Postmaster. These units may be sent by Railway Express with no restrictions.

CROSMAN ARMS CO. INC.

OCTOBER 1, 1959

Fairport, N. Y.

