

SECTION 5 - MAINTENANCE (CONT.)

<u>Paragraph</u>		<u>Page</u>
5.4.	COMPLETE VFO REMOVAL AND REPLACEMENT	5-12
5.5.	DIAL BULB AND STATIC DISCHARGE BULB REPLACEMENT	5-13
5.5.1.	Dial Bulb Replacement	5-13
5.5.2.	Static Discharge Bulb	5-13
5.6.	DIAL AND BAND CHANGE GEAR MAINTENANCE	5-13
5.6.1.	General.	5-13
5.6.2.	Disassembly of Gear Box.	5-13
5.6.3.	Reassembly of Gear Box	5-15
5.7.	RF TUNER ASSEMBLY MAINTENANCE	5-17
5.7.1.	General.	5-17
5.7.2.	Positions of Cams	5-17
5.8.	DIAL CORDS	5-18
5.8.1.	Megacycle Pointer Cord	5-18
5.8.2.	Drum Cord	5-19

SECTION 6 - PARTS LIST

SECTION 7 - PARTS IDENTIFICATION AND SCHEMATIC