

NOTE: To identify a part shown in one of these Views, so you can order a replacement, proceed as follows:

1. Note the identification number of the part (R-number, C-number, etc.).

2. Locate the same identification number (next to the part) on the Schematic. The "Description" of the part (for example: 22 k Ω , .05 μ F, or 2N2712) will also appear near the part.

3. Look up this Description in the Parts List.

