





BANDSWITCH


NOTE:
SEGMENT "E" OF SW1, SW2, SW3,
AND SW4 REMAIN WITHOUT
CONNECTION.

3.5 MHZ

7.0 MHZ

14 MHZ

21 MHZ



39
Q8

5.17
5.8

Q-7 da.

Q-5

Q-9 3V RF