

Coils L-1 through L-12 MUST BE CORRECTLY POSITIONED AND MOUNTED or the receiver will not work. Carefully, but firmly, insert the coils from the component side of the board. BE SURE THE NUMBER ON THE SIDE OF THE COIL FACES THE SAME NUMBER PRINTED ON THE BOARD. For example, L-4 must be mounted so that the 4 on the coil faces the 4 on the board, as shown in the detail on Figure 13.

- ☒ Mount L-5.
☒ Mount L-6.
☒ Mount L-8, with C-64 attached.
☒ Mount L-7.
☒ Mount L-12.
☒ Mount L-11.
☒ Mount L-4.
☒ Mount L-3.
☒ Mount L-1.
☒ Mount L-2.
☒ Mount L-9.
☒ Mount L-10.

