


PARTS LIST




41

COILS

Symbol Number	Description	Part Number
L-1	band A Antenna coil	162033
L-2	band B Antenna coil	162034
L-3	band C Antenna coil	162035
L-4	band D Antenna coil	162036
L-5	band E Antenna coil	162037
L-6	band A Oscillator coil	162038
L-7	band B Oscillator coil	162039
L-8	band C Oscillator coil	162040
L-9	band D Oscillator coil	162041
L-10	band E Oscillator coil	162042
L-11	BFO coil	162032




L-1 to L-10



L-11

RESISTORS


R-1	22K	301223
R-2	12K, 2 watt	307123
R-3	2.7K	301272
R-4	100K	301104
R-5	180Ω	301181
R-6	22K	301223
R-7	47K	301473
R-8	39K	301393
R-9	100K	301104
R-10	220K	301224
R-11	1.8K	301182
R-12	100K	301104
R-13	4.7 meg	301475
R-15	2.7K	301272
R-16	220K	301224
R-17	1 meg	301105
R-18	180Ω	301181
R-19	47K	301473
R-20	1.3K, 5%	302132
R-21	2.2 meg	301225
R-22	47K	301473
R-23	470K	301474
R-24	150Ω	301151
R-25	10K, 1 watt	304103
R-26	100K	301104
R-27	470K	301474
R-28	470K	301474
R-29	470K	301474
R-30	1 meg control with switch	390005
R-31	33Ω	301330
R-32	1 meg	301105
R-33	100Ω, 1 watt	304101
R-34	100K	301104
R-35	330Ω, 1 watt	304331



1/2 WATT RESISTOR



1 WATT RESISTOR



R-30