

PARTS LIST

R.F. SECTION

R-1,2,6	47,000 ohms - $\frac{1}{2}$ W.	C-29,30 ✓	3x10 - 500 V Electrolytic
R-3	120 ohms - $\frac{1}{2}$ W.	C-31	2x.0008 mfd- 600 V Ceramic
R-4	22 ohms - $\frac{1}{2}$ W.	C-32,33,	
R-5,18	5000 ohms - 10 W. ✓	34	500 mmf - 600 V Ceramic
R-7	25,000 ohms WW Pot.	L-1	Tapped Osc. Plate Coil
R-8	25,000 ohms - 10 W. ✓	L-2	20 M Osc. Plate Coil
R-9,10,12	22 ohms - 1 W.	L-3	Buffer Plate Coil
R-11	22 ohms - 2 W.	L-4	SSB Input Link
R-13	20,000 ohms - 20 W.	L-5	Final - Pi Network Coils
R-14	3,000 ohms - 10 W. ✓	J-1	Key Jack
R-15	1,000 ohms - 10 W.	J-2	SSB-VFO Input
R-16	2,500 ohms - 10 W.	J-3	Antenna
R-17	560 ohms - 1 W.	XTAL	Crystal socket
C-1	25 mmf - 600 V Ceramic	RFC-1	Osc. Cathode choke 2.5 MH-50MA
C-2	120 mmf - 600 V Ceramic	RFC-2	Buffer Plate choke 2.5 ME-125MA
C-3,4,6,7,		RFC-3	P.A. Grid choke 2.5 MH-125 MA
9,13,14,15,16,✓		RFC-4	P.A. Plate choke 1 MH-600 MA
17 ✓	.005 mfd - 600 V Ceramic	RFC-5,6,7,	
C-5	70 mmf variable	8,9	B / and Meter TVI Filter chokes
C-8	33 mmf - 600 V Ceramic	T-1	Filament Transformer
C-10	140 mmf variable	T-2	Screen and Bias Transformer
C-11	.001 mfd - 500 V Mica	Ch-1	Screen B / Filter choke
C-12 ✓	50 mmf - 500 V Mica	Ch-2	Modulation choke
C-18,20,35,		Sw-1	Meter Switch
36	500 mmf - 600 V Ceramic	Sw-2	Exciter Bandchange Switch
C-19 ✓	.002 mfd - 600 V Ceramic	Sw-3	SSB-AM Switch
C-21	500 mmf - 10,000 V Ceramic	Sw-4	Function Switch
C-22,23	500 mmf - 20,000 V Ceramic	Sw-5	P.A. Bandchange Switch
C-24	250 mmf variable	Sw-6	Impedance Selector Switch
C-25	350 mmf variable	FS-1	3 Amp. Fuse
C-26	Two .001 mfd - 2500 WVDC	RLY-1	Screen B / Relay
	in series	M-1	0-150 MA Meter
C-27,28	12 mfd -250V Electrolytic	M-2	0-400 MA Meter