

SECTION XI
PARTS LIST (RF SECTION)
(Contd)

FS-1	Fuse, 3 amp, 3AG	1	1500-002
J-1	Jack, key	1	2004-001
J-2	Jack, SSB Input	1	2000-002
J-3	Connector, antenna coax	1	2000-004
J-4	Connector, antenna coax	1	2000-004
L-1	Coil, Osc. Plate	1	1400-007A
L-2	Coil, Osc. Plate	1	1400-006
L-3	Coil, Buffer Plate	1	1400-004M
L-4	Coil, SB Input Link	1	1400-005
L-5A	Coil, 10M Final Plate	1	1400-029
L-5B	Coil, Final Plate, 20-40 M	1	1400-001
L-5C	Coil, Final Plate, 80-160M	1	1400-009
L-6	Coil, Matching 160 M	1	1400-010
M-1	Meter, 3" Shielded, 0-100 Ma	1	2500-006
M-2	Meter, 3" Shielded, 0-400 Ma	1	2500-008
PS-1	Parasitic Suppressor, buffer plate	1	1301-009
RFC-1	Choke, 2.4 MH, 50 Ma	1	1301-001
RFC-2	Choke, 2.5 MH, 200 Ma	1	1301-002
RFC-3	Choke, 2.5 MH, 200 Ma	1	1301-003
RFC-4	Choke, 1 MH, 600 Ma	1	1301-004
RFC-6	Choke, RF, Meter	1	1301-008
RFC-7	Choke, RF, Meter	1	1301-008
RFC-8	Choke, RF, Meter	1	1301-008
RFC-9	Choke, RF, Meter	1	1301-008
RFC-10	Choke, 2.5 MH, 200 Ma	1	1301-002
RLY-2	Relay, Antenna Changeover and Screen B Plus	1	3500-001
R-1	Resistor, 47K-1/2 watt	1	1000-002
R-2	Resistor, 1 meg, 1/2 watt	1	1000-023
R-3	Resistor, 47K-1 watt	1	1001-009
R-4	Resistor, 22K-1 watt	1	1001-010
R-5	Resistor, 120 ohm-1/2 watt	1	1000-003
R-6	Resistor, 56 ohm-1/2 watt	1	1000-010
R-7	Resistor, 6000 ohm-10 watt	1	1003-010
R-8	Resistor, 1 meg, -1/2 watt	1	1000-023
R-9	Potentiometer, 500 K	1	2300-001
R-10	Resistor, 47K-1/2 watt	1	1000-002
R-11	Resistor, 2500 ohm-10 watt	1	1003-005