

SECTION XI
PARTS LIST (MODULATOR SECTION)
(Contd)

R-40	Resistor, 100K ohm-1/2 watt	1	1000-009
R-41	Resistor, 50K ohm-50 watt	1	1006-002
R-44	Resistor, 47K ohm-1/2 watt	1	1000-002
ST-2	Terminal, Safety, Modulator B plus	1	2200-002
ST-3	Terminal, Safety, Modulator B plus	1	2200-002
SR-1	Rectifier, Push-to-Talk	1	3700-007
SO-3	Socket, Modulator power input	1	1600-007
SO-4	Socket, Push-to-Talk, connecting	1	2000-003
SW-8A	Switch, Modulator filament	1	2100-015
SW-8B	Switch, Modulator shorting		
SW-8C	Switch, Modulator plate control		
SG-1	Spark Gap Assembly	1	3900-002
SW-10	Switch, Compressor, ON/OFF	1	2101-001
T-3	Transformer, Audio Driver	1	1203-002
T-4	Transformer, Modulation	1	1203-004
T-5	Transformer, Speech Filament	1	1202-010
T-6	Transformer, Modulator Filament	1	1202-007
T-7	Transformer, Low B Plus Rectifier	1	1202-009
T-8	Transformer, High B Plus Rectifier	1	1202-002
T-9	Transformer, Dual High and Low B Plus Plate	1	1201-004