

SECTION XI  
PARTS LIST (POWER SUPPLY SECTION)  
(Contd)

|       |                                |   |           |
|-------|--------------------------------|---|-----------|
| RLY-6 | Relay, VFO B plus              | 1 | 3500-007  |
| RLY-7 | Relay, B plus Plate Control    | 1 | 3500-010  |
|       | Relay, Coil, for RLY-7         | 1 | 3500-011  |
| R-45  | Resistor, 100K ohm-1/2 watt    | 1 | 1000-009  |
| R-46  | Resistor, 50K ohm-20 watt      | 1 | 1004-002  |
| R-47  | Resistor, 75K ohm-100 watt     | 1 | 1008-001  |
| R-48  | Resistor, 22K ohm-1/2 watt     | 1 | 1000-008  |
| R-49  | Resistor, 56 ohm-1/2 watt      | 1 | 1000-010  |
| R-50  | Resistor, 100K ohm-1/2 watt    | 1 | 1000-009  |
| R-51  | Resistor, 3300 ohm-1 watt      | 1 | 1001-011  |
| R-52  | Resistor, 22K ohm-1/2 watt     | 1 | 1000-008  |
| R-53  | Resistor, 120 ohm-1/2 watt     | 1 | 1000-003  |
| R-54  | Resistor, 15K ohm-1/2 watt     | 1 | 1000-013  |
| SR-2  | Rectifier, VFO B Plus          | 1 | 3700-001  |
| SR-3  | Rectifier, VFO B Plus          | 1 | 3700-001  |
| ST-4  | Terminal, B Plus Safety        | 1 | 2200-002  |
| SO-5  | Socket, VFO Power              | 1 | 1600-007  |
| SO-6  | Socket, Push-to-Talk control   | 1 | 2000-003  |
| SO-7  | Socket, VFO Output             | 1 | 2000-006  |
| SO-8  | Socket, AC Power Output        | 1 | 1600-003  |
| T-10  | Transformer, filament, 866A    | 1 | 1202-006  |
| T-11  | Transformer, filament, 5U4G    | 1 | 1202-009  |
| T-12  | Transformer, VFO Power         | 1 | 1200-003  |
| T-13  | Transformer, High B plus Plate | 1 | 1201-006A |
| T-14  | Transformer, Low B plus Plate  | 1 | 1201-002  |