	MICROPHONE	KEY	Fuse	QUARTZ CRYSTAL
	CONTACT	Incondescent	EARTH GROUND	Contacts
Adjustable Inductance TRANSFORMERS	Fix —	LAMPS -	HEADSET	Receptacle
• Adjustable Coupling	Topped RESISTORS	Neon (AC)	<u>e</u> <u>e</u> <u>e</u> .	ا ي ا (
oling With Link	Adjustable	METERS In	, **	Coaxial Receptacie
O O O SPST	O Crossing Conductors	A-Ammeter V-Voltmeter Ma-Milliammeter MACHINE	INDUCTORS	Coaxiel Plug
SPDT Multi	Conductor		Adjustable >>>	Female A.
Multipoint 00000	Chassis	9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	* > ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	M ai•