



I Operation Instructions:

1. Loading and unloading bullets:

Hold the gun butt with hand, turn the lock handle to the right with thumb, and hold the barrel with the other hand, turn it downward to the limit, then put bullets into left and right barrel bores, turn the barrels back to the locking position, finish the loading. According to the above, turn the barrels downward to the limit, take out the shell cases, and again load bullets.

2. Shooting:

After putting bullets in, pull left or right hammer to the position ready for firing with hand, then prop lightly the gun butt end against shoulder, aim at target, press the trigger I or trigger II, firing is opened. (shooter may press trigger I or trigger II according to need.)

II Attention:

1. Before use, clean the barrels of the oil, avoid by all means blocking the barrels with cotton yarn, paper pieces, soil and snow, so that fatal accidents such as bore bursting or explosion can be prevented.

2. After shooting, clear away timely the powder remainders in the barrel and apply slosh. When atmosphere temperature is below -5°C , winter gun oil should be applied. Its parts should always keep clean against rust.

3. Take the bullets out of the barrel before surmounting an obstacle with the shotgun, meanwhile, pay attention not to lean the shotgun loaded with bullets freely on unsafe objects such as vehicles, indoor walls, doors, etc., so as to avoid accidents.

4. Take bullets out of the bore when shotgun is not in use. For ensuring safety, regular examination should be made to degree of wear and tear in the two joints between left and right firing lock lever and left and right ratched-wheel.

