

## **GX® -4 QUICK REFERENCE CARD**

### **BASIC OPERATION**

- Press POWER to acquire a target.
- Press and hold MODE for at least 1 second to enter the Quick Set Menu.
- Once you have entered the Quick Set Menu, press and release MODE to navigate through the menu options.
- Press POWER to adjust the currently displayed mode.
- To reset factory settings, press and hold MODE, then immediately press and hold POWER for at least 10 seconds.



### **TRUE GOLF RANGE (WITH YELLOW SMART KEY ONLY)**

- True Golf Range (TGR) provides accurate ranging information matched to the slope of the shot and current conditions to compensate for uphill shots that play long and downhill shots that play short.
- To Activate TGR:
  - Press POWER to activate the rangefinder.
  - Press and hold MODE for at least 1 second to enter the Quick Set Menu.
  - Press and release MODE once; "TGR" will be shown in the upper portion of the display. Press and release POWER as necessary until the word "on" is shown in the bottom of the display.
  - To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.

### **SETTING THE CURRENT TEMPERATURE AND ALTITUDE (WITH YELLOW SMART KEY ONLY)**

- Temperature and altitude are some of the factors used to determine TGR ranges; inputting the current conditions will increase the accuracy of your TGR measurement. TGR must be activated to input the current conditions.
- To input the current conditions:
  - Activate TGR.
  - Press and release MODE; The last saved temperature will be flashing.

## **CURRENT TEMPERATURE AND ALTITUDE (CONTINUED)**

- Pressing and releasing POWER will increase the current temperature setting by 5 degrees; press MODE to save the appropriate setting and move to the current altitude input.
- Pressing and releasing POWER will increase the current altitude by 500 feet.
- To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.

## **CLUB SELECTOR SETUP**

- When TGR is activated, the Club Selector recommends the proper iron for the current distance, shot angle, environmental conditions, and multiple other factors.
- TGR must be activated to obtain club recommendations.
- Specific distances obtained with your 8-iron, 6-iron, and 4-iron must be input prior to initial use.
- To input specific distances:
  - Activate TGR, input the current temperature and altitude, and select between yards or meters as the desired output unit.
  - After selecting yards or meters, press and release MODE.
  - The last saved distance for an 8-iron shot will be displayed; press and release POWER until the appropriate distance is displayed; then press MODE.
  - Follow the same procedure for your 6-iron and 4-iron striking distances.
  - You will be asked to input the proper temperature and altitude at which each distance was obtained. Follow the same procedure using POWER to change the setting and MODE to advance to the next step. Accurately entering this information will tell your GX-4 how to properly adjust for current conditions.
- To save current settings let the rangefinder automatically power-down (20 seconds) or simply press and hold MODE for at least 1 second.