




START

- () 220 Ω (red-red-brown).
- () .047 μ fd Mylar.
- () .1 μ fd Mylar.
- () 1 megohm (brown-black-green).
- () 22 megohm (red-red-blue).
- () 47 K Ω (yellow-violet-orange).
- () 12 K Ω 2 watt (brown-red-orange).



- () 4700 Ω (yellow-violet-red).
- () 47 K Ω (yellow-violet-orange).
- () .005 μ fd disc.
- () Solder all connections and cut off excess leads.
- () 100 K Ω (brown-black-yellow).
- () .005 μ fd disc.

NOTE: Position the banded end of germanium diodes as shown.

- () Germanium diode. Use 1/4" of sleeving on each lead.
- () 220 Ω (red-red-brown).
- () 36 pf mica.
- () Germanium diode. Use 1/4" of sleeving on each lead.
- () .02 μ fd disc.
- () 1000 Ω (brown-black-red).
- () Germanium diode. Use 1/4" of sleeving on each lead.
- () .47 μ fd Mylar. Be careful when bending the leads so they do not pull out of the capacitor.
- () Solder all connections and cut off excess leads.

CONTINUE

- () .005 μ fd disc.
- () 18 pf disc.
- () 4700 Ω (yellow-violet-red).
- () 220 K Ω (red-red-yellow).
- () 47 K Ω (yellow-violet-orange).
- () 1 megohm (brown-black-green).
- () .02 μ fd disc.
- () .02 μ fd disc.
- () 1-3/4" jumper.
- () 500 pf disc.
- () Solder all connections and cut off excess leads.
- () 1-7/8" jumper.
- () .005 μ fd disc.
- () .005 μ fd disc.
- () .02 μ fd disc.
- () Germanium diode. Use 1/4" of sleeving on each lead.
- () 220 Ω (red-red-brown).
- () 36 pf mica.
- () 500 pf disc.
- () 1000 Ω (brown-black-red).
- () Solder all connections and cut off excess leads.

BOARD SECTIONS 1B AND 1C

NOW PERFORM THE STEPS ON PICTORIAL 1-4.

PICTORIAL 1-3