



INSTALL WASHERS AT BOTH  
ENDS OF C-16

FIGURE 15. MOUNTING C-16 (TRIMMER STRIP)

#### SEE FIGURE 15.

- ✓ Good electrical contact between the foil side of the RF board and the RF subchassis is necessary for proper operation of your receiver. The foil side of the RF board may be coated with a protective layer of rosin. Remove it by lightly touching your hot soldering iron around the holes marked with an asterisk (\*) as shown in Figure 15. The rosin will melt and a clean, shiny spot will appear.
- ✓ The bracket of C-16 (the trimmer strip with C-63 attached) must be raised from the RF board. To mount C-16 use the two 6-32 x 7/16" screws as follows: Insert each screw through a lockwasher, through the C-16 bracket, through two flat washers, and through the RF board. Tighten a nut over each screw.
- ✓ Solder one end of a 1 1/4" bare wire in hole C. Solder the other end to terminal 6 of C-16.
- ✓ Push a 1/2" piece of spaghetti over a 1" bare wire. Solder one end of this wire in hole B. Solder the other end to terminal 5 of C-16.
- ✓ Solder one end of a 1" bare wire in hole D. Connect, but do not solder, the other end to terminal 7 of C-16.
- ✓ Solder one end of a 1 1/2" bare wire in hole E. Connect, but do not solder, the other end to terminal 8 of C-16.
- ✓ Solder one end of a 1" bare wire in hole H. The other end will be connected later.
- ✓ Solder one end of a 3/4" bare wire in hole J. The other end will be connected later.